HENRY® VARPOR BARRIER

Fast-Track, One-Component Moisture Vapor Barrier



For RH readings up to 100%

For absorbent concrete

No minimum profile required

No priming required prior to installation of HENRY underlayments

Fast drying - install HENRY underlayments in as little as 60 minutes after applying the second coat







