

HENRY®

HENRY® 695 High RH Vinyl Flooring Adhesive

Designed for installing LVT as well as vinyl sheet goods

99% RH moisture resistant*

May be used in a dry-to-the-touch (pressure-sensitive) state, or as a wet-set

Excellent resistance against plasticizer migration

4 hours of Working Time available if needed

Solvent-free, acrylic polymer-based adhesive

Overall versatility and outstanding bond strength

Unit Sizes:

1-gallon / 3.78 L Pail

4-gallon / 15.14 L Pail



ARDEX Americas
400 Ardex Park Drive
Aliquippa, PA 15001 USA
888-512-7339
www.wwhenry.com

HENRY 695 High RH

Vinyl Flooring Adhesive

Suitable Applications and Flooring Types*

- When the specific guidelines for installation from the flooring manufacturer call for a fully adhered, glue-down installation; for flooring types not listed, contact the ARDEX Technical Service Department.
 - Vinyl tile / plank (LVT, SVT, VCT, VET)
 - Fiberglass encapsulated / cushion backed Sheet vinyl
 - Felt backed, Heterogeneous and Homogeneous Sheet vinyl

Recommended Tools and Coverage*

Trowel notch sizes and spread rates are guidelines. It is the responsibility of the installer to apply enough adhesive based on the needs of the floor covering and the condition of the substrate.

All Substrates, All Suitable Applications:

Sq. notch trowel 1/16" D x 1/16" W x 1/16" A

Coverage Per 4-Gallon (15.14 L) Unit: Up to 1,000 sq. ft. / 92.9 sq. m



Alternate trowel for extremely flat substrates:

U-notch trowel 1/32" D x 1/16" W x 5/64" A

Note - minor imperfections on the surface of the substrate, such as concrete trowel marks and pitting, must not exceed the 1/32" (0.7 mm) height of the adhesive trowel ridge.

Coverage Per 4-Gallon (15.14 L) Unit: Up to 900 - 1,100 sq. ft. / (83.6 - 102.1 sq. m)



Suitable Substrates*

- Concrete (structurally sound)
- Absorbent terrazzo on concrete
- Patching, leveling or fill materials
- Untreated APA-grade underlayment plywood†
- Properly primed Gypsum underlayments (above-grade only)
- Radiant-heated subfloors not to exceed 85°F (29°C)
- Other approved, non-porous materials on concrete:†
 - Ceramic, quarry or porcelain tiles
 - Non-porous (non-absorbent) cementitious terrazzo
 - Epoxy terrazzo
 - Existing resilient flooring (fully adhered, non-cushion backed)
 - Certain metals and Epoxy Coatings (Contact the ARDEX Technical Service Department before proceeding further)

*Refer to the specific recommendations of the flooring manufacturer for suitable substrates. Please note that all substrates must be clean, sound, solid, well bonded and prepared as detailed below.

HENRY flooring adhesives have a long-standing successful track record of use with a wide range of floor coverings. Always follow the advice of the flooring manufacturer. Contact the ARDEX Technical Service Department for further guidance

†Must be sound, solid and well-bonded to underlying, structurally sound substrates.

Dimensional Stability of Flooring Structures

Some floor coverings may grow or shrink as a result of acclimation, handling and/or how the products were manufactured. Install representative test areas to determine the suitability of this adhesive to resist any dimensional change. Please note that ARDEX Americas cannot be held responsible for installation issues caused by dimensional changes in flooring structures.

Step 1: Moisture Evaluation and Testing

Test concrete in accordance with ASTM F2170. **For high-moisture floor coverings and under the following conditions, this product can be installed over concrete with relative humidity (RH) levels not to exceed 99%:

- Each on-ground slab is built on a vapor retarder, which remains effective and intact, in conformance with ASTM E1745.
- Alkali readings should not exceed 12 pH.
- Concrete must be a minimum of 45 days old.
- Concrete slab must be at service temperature, and occupied air space above the slab must be at service temperature and service relative humidity, at time of installation.
- Relative humidity of air within the space cannot exceed 65% for 72 hours following installation.

All other cases: Moisture control is required if the RH exceeds the limitations imposed by the flooring manufacturer.

Step 2: Job Preparation

Refer to the specific recommendations of the flooring manufacturer for substrate preparation. Acclimate the installation area, adhesive and flooring in an enclosed building at a minimum of 65°F (18°C) for at least 48 hours before, during and for 48 hours after installation (High-moisture applications: 72 hours).

Step 3: Substrate Preparation (Proper Prep™)

If necessary, mechanically clean the substrate by shot blasting or similar means. Do not use acid etching, adhesive removers, solvents or sweeping compounds, as these are bond breakers. Sanding is not an effective method to remove contaminants from concrete.

Substrate must be dry and alkali free. All substrates must be sound, solid and thoroughly clean of all bond-breaking contaminants, including but not limited to: overwatered or otherwise loose or weak material; dirt, dust, wax, grease, paints and oils; all curing compounds and sealers.

Substrate must be sound, smooth and flat in accordance with finish manufacturer requirements. Ensure that the substrate is solid and fixed securely to provide a rigid base free of undue flex. Address rough unsmooth areas, cracks, holes and levelling needs with appropriate substrate preparation products.

While this product is resistant to being damaged by high concrete moisture vapor emissions, it does not create a moisture barrier and, therefore, does not protect finish materials from concrete moisture. Address concrete moisture as needed with appropriate moisture control materials.

Following preparation, thoroughly vacuum to remove all excess dirt and debris.

Handle and dispose of asbestos and other hazardous materials in accordance with prevailing regulations, which supersede the recommendations in this document.

Step 4: Application

Follow the guidelines from the flooring manufacturer for layout, design and suitable installation methods. Remove lid and stir any liquid found on the surface into the adhesive. This adhesive is ready-to-use and does not require mixing.

Application Data

Physical properties are typical values and not specifications. All data based on 70°F / 21°C.

Dry-to-the-touch (pressure-sensitive) applications:

Approximate Required Open time:	30-60 minutes
Maximum Open time:	4 hours

Semi-wet-set applications (porous substrates only):

Approximate Required Open time:	5-10 minutes
Maximum Open time:	5-10 minutes

Instructions

- Apply adhesive evenly using the recommended proper tool.
- See “maximum open time” above. Do not apply more adhesive than can be covered within approximately this time period.
- See “approximate required open time” above. Before installing flooring, allow the troweled adhesive to set open for this amount of time. For pressure-sensitive applications, ensure that the adhesive reaches a dry-to-the-touch state (tacky, but no transfer to fingers.)
- Roll the installed floor across width and length using a 3-section 100 lb heavy roller as recommended by the flooring manufacturer. Weight down seams as recommended by the flooring manufacturer.

Step 5: Cleanup

Remove wet adhesive residue with a clean, white cloth dampened with soapy water. Use mineral spirits for dried adhesive residue. When using mineral spirits, carefully follow the recommendations of the manufacturer, and test a small area before proceeding to make sure it does not damage the surface being cleaned.

Step 6: Time to Traffic

12 hours. Protect all floor coverings when moving heavy appliances and/or when rolling loads are utilized.

Notes

Never mix with cement or additives outside of our written recommendations. In accordance with industry standards, and to determine the suitability of the products for the intended use, always install an adequate number of properly located test areas, including the finish flooring. As floor coverings vary, always contact and rely upon the floor covering manufacturer for specific directives, such as maximum allowable moisture content, adhesive selection and intended end use of the product. If the installation is not proceeding as expected: Contact the ARDEX Technical Service Department before proceeding further. Contact the ARDEX Technical Service Department before proceeding further.

Observe the basic rules of concrete work, including the minimum surface and air temperatures detailed above. Install quickly if the substrate is warm, and follow the warm weather installation guidelines available on our website.

Dispose of packaging and residue in accordance with prevailing regulations. Do not flush material down drains. Do not reuse packaging.

Technical Data According to Manufacturer Quality Standards

Physical properties are typical values and not specifications.

VOC:	2.3 g/L; SCAQMD 1168
Storage:	Store in a cool, dry area. Do not leave units exposed to sun. Freeze-thaw stable to 10°F / -12°C. Avoid multiple freeze-thaw cycles.
Shelf Life:	12 months, if unopened and properly stored.
Warranty:	10-Year Limited HENRY'S BEST WARRANTY. Also eligible for ARDEX SystemOne™ Warranty. For full warranty details: ardexamericas.com/services/warranties .

Precautions

Carefully read and follow all precautions and warnings on the product label. For complete safety information, please refer to the Safety Data Sheet (SDS) available at:

www.wwhenry.com.

Made in the USA.

Copyright 2024 ARDEX, L.P. All rights reserved. Content updated 2024-04-04. Supersedes all previous versions.

Latest version available at:

www.wwhenry.com.

Visit www.youtube.com/ARDEX101 to watch ARDEX product demonstration videos. For recommended installation tools, visit DTA USA at www.dtausagroup.com. For easy-to-use ARDEX Product Calculators and Product Information On the Go, download the ARDEX App.



www.wwhenry.com

ARDEX Americas
400 Ardex Park Drive
Aliquippa, PA 15001 USA
888-512-7339